

RENTAL EQUIPMENT TEST PROCEDURE





LOAD FUNCTION

At operating voltage displaying the no load current for comparison

Note - load and leakage testing measurements may be taken at the same time by some test equipment





Clare, Bracken Hill, South West Industrial Estate, Peterlee, Co. Durham, SR8 2SW Tel. +44 (0) 191 587 8744 Fax. +44 (0) 191 586 0227 Web. www.clare.co.uk